
Voltage Divider Output Signal

Compact Mid-Range String Pot • Absolute Position 80, 120-inch Stroke Range Options Polycarbonate Enclosure • IP67 In Stock for Quick Delivery



SPECIFICATIONS

Stroke Range Options	80 inches (2032)	mm), 120 inches (3048 mm)
Output Signal	volta	ge divider (potentiometric)
Accuracy		.35% FS.
Repeatability		.05% FS.
Resolution		essentially infinite
Measuring Cable	.019-inch dia. n	ylon-coated stainless steel
Maximum Acceleration		10 g
Measuring Cable Tension		9 oz. (2,5 N) ±30%
Sensor	plastic-hybr	id precision potentiometer
Input Resistance		10K ohms, ±10%
Power Rating, Watts		2.0 at 70°F
Recommended Maximum I	nput Voltage	30 V (AC/DC)
Output Signal Change Ove	r Full Stroke Range	94% ±4% of V(+in)
Cycle Life		≥ 250,000
Electrical Connection		see ordering information
Enclosure		glass-filled polycarbonate
Environmental	IP 50 , IP67 (m12 c	onnector & pigtail options)
Operating Temperature		-40° to 160° F (-40° to 70° C)
Weight, 80-inch (not includ	ing bracket)	.6 lbs. (272 g)
Weight, 120-inch (not inclu	ding bracket)	1 lb. (453 g)




The SG1 provides absolute linear position up to a 10-ft. stroke range. Constructed with a rugged polycarbonate body, this model is available in an 80-inch or 120-inch stroke range and offers optional IP67 protection for wet or outdoor installations and an M12 connector for easy installation.

The SG1 uses a precision high-cycle plastic hybrid potentiometer and an extremely durable spring-loaded stainless steel measuring cable to provide an accurate reliable position feedback signal over the entire stroke. With it's slim design and versatile mounting



bracket, the SG1 has been designed to fit into spaces no other measurment device can. For the OEM customer, custom mounting hardware and electrical connections are available.

ORDERING INFORMATION







13-ft. cordset with a 4-pin M12 connector is available


for the SG1-80-3 and SG1-120-3.

Electrical Connection:

+in


+out


common





*note: connector pin 4 and the black wire on the cordset are NOT used.

Output Signal:











Mounting Options (SG1-80, SG1-80-2, SG1-80-3):





Mounting Options (SG1-120, SG1-120-2, SG1-120-3):



tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799


SG1-80 w/o Mounting Bracket:






*tolerance = +.005 -.001 [+.13 -.03] **tolerance = +.005 -.005 [+.13 -.13]


SG1-120 w/o Mounting Bracket:







*tolerance = +.005 -.001 [+.13 -.03] **tolerance = +.005 -.005 [+.13 -.13]


SG1-80 w/ Mounting Bracket:



*tolerance = +.005 -.001 [+.13 -.03] **tolerance = +.005 -.005 [+.13 -.13]










INCHES [MM]


SG1-120 w/ Mounting Bracket:



*tolerance = +.005 -.001 [+.13 -.03] **tolerance = +.005 -.005 [+.13 -.13]









INCHES [MM]

SG1-80-2 w/ Mounting Bracket:




*tolerance = +.005 -.001 [+.13 -.03] **tolerance = +.005 -.005 [+.13 -.13]




SG1-120-2 w/ Mounting Bracket:

INCHES [MM]




*tolerance = +.005 -.001 [+.13 -.03] **tolerance = +.005 -.005 [+.13 -.13]




INCHES [MM]

SG1-80-3 w/ Mounting Bracket:



SG1-120-3 w/ Mounting Bracket:




Version: 3.0 last updated: February 4, 2013


SGD

4..20mA • 0..10 Vdc Output Signal

Compact Mid-Range String Pot • Absolute Position 80, 120-inch Stroke Range Options Polycarbonate Enclosure • IP67

In Stock for Quick Delivery





SPECIFICATIONS

Stroke Range	80 inches (203	2 mm), 120 inches (3048 mm)
User Selectable Output Sig	gnal	420 mA (2-wire) / 010 Vdc
Input Voltage, 420 mA op	otion	8-40 VDC
Input Voltage, 010 Vdc op	otion	12-32 VDC
Accuracy		.35% FS.
Repeatability		.05% FS.
Resolution		essentially infinite
Measuring Cable	.019-inch dia	nylon-coated stainless steel
Maximum Acceleration		10 g
Measuring Cable Tension		9 oz. (2,5 N) ±30%
Sensor	plastic-hy	brid precision potentiometer
Cycle Life		≥ 250,000
Electrical Connection	M12 conn	ector (mating plug included)
Enclosure		glass-filled polycarbonate
Environmental		IP 67
Operating Temperature		0° to 160° F (-18° to 70° C)
Weight, 80-inch (not include	ding bracket)	.6 lbs. (272 g)
Weight, 120-inch (not inclu	1 lb. (453 g)	




Suited for IP67 (wet) environments, the SGD provides a user-selectable 4-20mA or 0-10VDC absolute linear position signal over an 80-inch or 120-inch full stroke range option. Signal selection is simply made by connecting the appropriate pins on the included connector or selecting the proper wires in the optional cordset.

Additionally, this sensor is constructed with a rugged polycarbonate body, an extremely durable spring-loaded stainless steel measuring cable and a mounting bracket that lets the customer mount this sensor in just about any direction. The SGD is in stock for quick delivery.

Customized options are also available for OEM customers.

Output Signal:



*note: signal endpoints are set at the time of manufacture and cannot be adjusted

ORDERING INFORMATION




SGD-80-3 and SGD-120-3.


20630 Plummer Street • Chatsworth, CA 91311 tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799










field installable connector (included)





cordset, part no. 9036810-0040 (optional)













Mounting Options (SGD-120-3):






tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799



3.80 [96,4]

SGD-120-3 w/ Mounting Bracket:



2.47 [62,7] -

INCHES [MM]



SGH

CANopen Output Signal

Compact Mid-Range String Pot • Absolute Position 80, 120-inch Stroke Range Options Rugged Polycarbonate Enclosure • IP67 In Stock for Quick Delivery


GENERAL

Stroke Range Options	80 inches (20	32 mm), 120 inches (3048 mm)
Accuracy		.5% FS.
Repeatability		.05% FS.
Resolution		12-bit
Input Voltage		10-36 VDC
Input Current		100 mA, max.
Measuring Cable	.019-inch d	ia. nylon-coated stainless steel
Measuring Cable Tension, 80)-inch	14 oz. (3,9 N) ±30%
Measuring Cable Tension, 12	20-inch	9 oz. (2,5 N) ±30%
Maximum Acceleration		10 g
Sensor	plastic-h	ybrid precision potentiometer
Cycle Life		≥ 250,000
Electrical Connection	M12 con	nector (mating plug included)
Enclosure		glass-filled polycarbonate
Environmental		IP 67
Operating Temperature		-40° to 200° F (-40° to 90° C)
Weight, 80-inch (not includi	ng bracket)	.6 lbs (272 g)
Weight, 120-inch (not include	ling bracket)	1 lb. (454 g)

CANopen SPECIFICATIONS

Communication Pr	ofile CiA 301 V 4.0.2, CANopen Slave
Device Type	CiA 406 V3.2, Encoder
Vendor ID	Company x0002E0, Dept x00
Node ID	1-127 (Adjustable via dipswitch or LSS, default set to 1)
Baud Rate Options	125K (default), 250K, 500K, 1M
Data Rate	50ms (default)
Error Control	Heartbeat, Emergency Message
PDO	2 TxPDO, 0 RxPDO, no linking, static mapping
PDO Modes	Event / Time triggered, Synch / Asynch
SDO	1 server, 0 client
Position Data	Object Dictionary 6004
Cam Switches	Not Supported
Termination Resiste	or See Ordering Information





A perfect solution for both OEM and single-piece user, this string pot provides an economically priced CANopen sensor for 80-inch and 120-inch stroke range applications. This sensor is constructed with a rugged polycarbonate enclosure, a stainless steel mounting bracket and universally accepted M12 connector for operation in both outdoor or factory dry environments. For the OEM, customized options are available.

ORDERING INFORMATION

w/o terminating resistor




SGH-80-4

80-inch stroke range, no terminating resistor 5-pin M12 mating plug, mounting bracket. SGH-120-4

120-inch stroke range, no terminating resistor 5-pin M12 mating plug, mounting bracket.

w/ terminating resistor



SGH-80-4-TR

80-inch stroke range, terminating resistor, 5-pin M12 mating plug, mounting bracket. Part No.
SGH-120-4-TR

80-inch stroke range, terminating resistor, 5-pin M12 mating plug, mounting bracket.



Optional Cordset

Part No. 9036810-0030

for short-run connections, a convenient optional 16-ft. cordset with a 5-pin M12 connector.




Field Installable Connector


9036810-0032


While every SGH ships with a field installable 5-pin M12 mating plug, additional connectors are available.













Position Data Overview:








LSS, Baud Rate and Node ID settings:

LSS, Baud Rate and Node ID settings are set via dip switch found on the internal controller board. To gain access to the controller board, remove the 4 cover attaching screws and carefully separate the sensor cover from the main body. Be careful not to damage the small gage wires that connect the potentiometer to the controller board mounted directly to the rear cover.

Follow the instructions below for desired settings and reinstall sensor cover.

Settings (cont.):



LSS Settings:

IF DIP Switch 1 is set to "on" position, then LSS will be functional and uses the contents of EEPROM including Node ID and Baud Rate. If DIP Switch 1 is set to "off" position, then DIP switches will override information in EEPROM including the Node ID and Baud Rate.

BAUD Rate:

If DIP Switch 1 is set to "off" then BAUD rate is set via DIP switch 2 and 3 as shown:

transmission rate options

baud rate	SW2	SW3
125 kbps	off	off
250 kbps	on	off
500 kbps	off	on
1 Mbps	on	on

node ID	
options	
1–127	
(0x01-0x7F)	

ne	ode ID	SW4	SW5	SW6	SW7	SW8	SW9	SW10
Dec	. Hex	(2°)	(2 ¹)	(2 ²)	(2 ³)	(2 ⁴)	(2 ⁵)	(2 ⁶)
1	0x01	on	off	off	off	off	off	off
2	0x02	off	on	off	off	off	off	off
3	0x03	on	on	off	off	off	off	off
126	0x7E	off	on	on	on	on	on	on
127	0x7F	on	on	on	on	on	on	on

Node ID:

If DIP Switch 1 is set to "off" then the Node ID is set via DIP switches 4 – 10 as shown below. The DIP switch settings are binary starting with switch number 4 $(=2^{\circ})$ and ending with switch number 10 $(=2^{\circ})$.

The Node ID is equal to the binary setting.

Manufacturer Objects:

Index	Sub-Index	Name	Default	Comment
2000		Raw Position Value		This is the averaged, non-scaled value from the encoder.
2001		Emergency Buffer Distance	0.1	Emergency Message is sent when the output of the sensing potentiometer is outside it's calibrated range by more than .1% of the sensors full measurement range (Emergency Buffer). This allows for non-repeatability of sensor and customers application. This object allows user ability to change buffer size along with transmission of Emergency Message, Manufacturer specific bit in error register set, and error added to error list.

Device Profile Area:

Index	Sub-Index	Name	Default	Comment
6000		Operating Parameters	0X0000	
6004		Position Value	0	Counts proportional to measuring cable extension. Nominal values are 0x008 with cable fully retracted and 0xFE5 with cable fully extended. Format of data in CAN message is little endian – least significant byte pair first. Therefore 0x008 would be shown as "08 00" and 0xFE5 would be shown as "E5 0F"
6400		Area State Register		SubNumber= 2 (indicates underflow or overflow per CiA406)
	0	Highest Subindex	0x01	
	1	Work Area State Channel 1	0	

<u>Device Profile Area (cont.):</u>

6401		Work Area Low Limit		The averaged, non-scaled (raw) encoder data below which the encoder is out of range.
	0	Highest Subindex	0x01	
	1	Work Area Low Limit Channel1	0x024	
6402		Work Area High Limit		The averaged, non-scaled (raw) encoder data above which the encoder is out of range.
	0	Highest Subindex	0x01	
	1	Work Area High Limit Channel 1	0xF4E	
6500		Operating Status	0x0000	
6501		Measuring Step	1	Position Measuring Step. Can be set by user to convert Position Value (Object 6004) to measurement units (inches, mm). Default is set to 1.

Communication Area Profile:


Index	Sub-Index	Name	Default	Comment
1000		Device Type	0X00080196	Device Profile 406
1001		Error Register	0	Manufacturer Specific Error bit 7 is set when sensor is outside of calibrated range and cleared when back in range.
1003		Pre-Defined Error Field		SubNumber= 9 (lists last eight Emergency Messages)
	0	Number of Errors	0	
	1	Standard Error Field 1		
	2	Standard Error Field 2		
	3	Standard Error Field 3		
	4	Standard Error Field 4	[
	5	Standard Error Field 5		
	6	Standard Error Field 6	ļ	
	7	Standard Error Field 7		
	8	Standard Error Field 8	ļ	
1005				
1010		Store Parameters	ļ	SubNumber=2
1010	0	Highest Subindex	0x01	Only "Save All Parameters" feature supported
	1	Save All Parameters		Write "save" or "evsa" to save parameters to EEPROM. They are automatically loaded on power up/reset. Saves the value of all R/W object dictionary entries.
1014		Emergency COB-ID	\$NodeID + 0x80	COB-ID Emergency Message
1015		Emergency Inhibit Time	0	Multiple of 100us. Minimum time between transmissions of emergency messages.
1017		Producer Heartbeat Time	0	Multiples of 1ms. Time between transmission of heartbeat messages. 0 = disabled

now part of Measurement Specialties, Inc.


Communication Area Profile (cont.):

1018		Identity Object		
	0	Number of Entries	4	
	1	Vendor Id	0x2E0	
	2	Product Code	269 (decimal)	Celesco Reference # 604269
	3	Revision Number	1	
	4	Serial Number	0x00000000	
1800		Tx PDO Comm. Parameter		PDO1
	0	Number of Entries	5	
	1	COB-ID	\$NodeID + 0x108	COB-ID used by PDO1
	2	Transmission Type	254	PDO1 Tx Type: 0 = on Sync Message. 254 = Asynchronous Tx
	3	Inhibit Time	0	Multiple of 100us. Minimum time between transmissions of the PDO
	5	Event Timer	0x32	If non-zero then transmits the PDO periodically. This value is a multiple of 1ms.
1801		Tx PDO Comm. Parameter		PDO2
	0	Number of Entries	5	
	1	COB-ID	\$NodeID + 0x280	COB-ID used by PDO2
	2	Transmission Type	0	PDO2 Tx Type: 0 = on Sync Message. 254 = Asynchronous Tx
	3	Inhibit Time	0	Multiple of 100us. Minimum time between transmissions of the PDO
	5	Event Timer	0	If non-zero then transmits the PDO periodically. This value is a multiple of 1ms.
1A00		Tx PDO Mapping Parameter		Subnumber = 2
	0	Number of Entries	1	
	1	PDO Mapping Entry	0x60040020	Mapping Parameter
1A01		Tx PDO Mapping Parameter		Subnumber = 2
	0	Number of Entries	1	
	1	PDO Mapping Entry	0x60040020	Mapping Parameter

80-inch SGH-80-4 w/ Mounting Bracket:



120-inch SGH-120-4 w/ Mounting Bracket:





tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799


Mounting Options:

Changing Measuring Cable Exit and Electrical Connector Direction:


For the ultimate in flexibility, the measuring cable exit direction and the direction of the electrical connector can be rotated around in 90° increments to accommodate just about any installation requirement.

To change measuring cable exit direction, simply remove the 4 mounting bracket screws, rotate the bracket to desired position and replace the screws.


To change the direction of the electrical connector, remove the 4 sensor cover screws and carefully remove the sensor cover just far enough to separate the cover from the main body. Be careful of the three small gage wires that attach the internal controller board to the potentiometer.



Mounting Option Mounting Dimensions (SGH-80-4):



Mounting Option Mounting Option Dimensions (SGH-120-4):



version: 1.4 last updated: January 21, 2013



SGJ

SAE J1939 CANBus Output Signal

Compact Mid-Range String Pot • Absolute Position 80, 120-inch Stroke Range Options Polycarbonate Enclosure • IP67

In Stock for Quick Delivery


GENERAL

Stroke Range Options	80 inches (203	2 mm), 120 inches (3048 mm)						
Accuracy		.5% FS.						
Repeatability		.05% FS.						
Resolution		12-bit						
Input Voltage		10-36 VDC						
Input Current		100 mA, max.						
Measuring Cable	.019-inch dia	a. nylon-coated stainless steel						
Measuring Cable Tension, 80	-inch	14 oz. (3,9 N) ±30%						
Measuring Cable Tension, 12	0-inch	h 9 oz. (2,5 N) ±30%						
Maximum Acceleration		10 g						
Sensor	plastic-hy	brid precision potentiometer						
Cycle Life		≥ 250,000						
Electrical Connection	M12 conr	nector (mating plug included)						
Enclosure		glass-filled polycarbonate						
Environmental		IP 67						
Operating Temperature		-40° to 200° F (-40° to 90° C)						
Weight, 80-inch (not includin	ng bracket)	.6 lbs (272 g)						
Weight, 120-inch (not includi	ng bracket)	1 lb. (454 g)						

CANbus SPECIFICATIONS

Communication Profile	CANbus SAE J1939
Protocol	Proprietary B
Node ID	Adjustable via dipswitch (0-63), default set to 0
Baud Rate Options	125K (default), 250K, 500K, 1M
Data Rate Options	5ms (default), 20ms, 50ms, 100ms
Termination Resistor	See Ordering Information





The economically priced SGJ provides linear position sensing over J1939 CANbus for OEM, mobile equipment and factory automation applications. Designed to withstand IP67 environments, the SGJ is constructed with a rugged polycarbonate body, an extremely durable spring-loaded stainless steel measuring cable and a stainless steel mounting bracket. For the OEM, customized options are available.

ORDERING INFORMATION

w/o terminating resistor



SGJ-80-4
80-inch stroke range,
no terminating resistor,
5-pin M12 mating plug,
mounting bracket included

SGJ-120-4
120-inch stroke range,
no terminating resistor,
5-pin M12 mating plug,
mounting bracket included

w/ terminating resistor



SGJ-80-4-TR

80-inch stroke range, with terminating resistor, 5-pin M12 mating plug, mounting bracket.

SGJ-120-4-TR

80-inch stroke range, with terminating resistor, 5-pin M12 mating plug, mounting bracket.



Optional Cordset

Part No. 9036810-0030

for short-run connections, a convenient optional 16-ft. cordset with a 5-pin M12 connector.





Field Installable Connector


Part No. 9036810-0032

While every SGJ ships with a field installable 5-pin M12 mating plug, additional connectors are available.











Position Data Overview:





Baud, Node ID and Data Rate:

Baud Rate, Node ID and Data Rate settings are set via dip switch found on the internal controller board. To gain access to the controller board, remove the 4 cover attaching screws and carefully separate the sensor cover from the main body. Be careful not to damage the small gage wires that connect the potentiometer to the controller board mounted directly to the rear cover.

Follow the instructions below for desired settings and reinstall sensor cover.








	off	2 3 4 5 6 7 8	9 10
	Data Rate	SW9	SW10
(5 ms	off	off
Data Rate	20 ms	on	off
options	50 ms	off	on
(100 ms	on	on

node ID options 0–63 (0x00–0x3F)

no	de ID	SW1	SW2	SW3	SW4	SW5	SW6
Dec.	Hex	(2°)	(2 ¹)	(2 ²)	(2 ³)	(2 ⁴)	(2 ⁵)
0	0x00	off	off	off	off	off	off
1	0x01	on	off	off	off	off	off
2	0x02	off	on	off	off	off	off
3	0x03	on	on	off	off	off	off
62	0x3E	off	on	on	on	on	on
63	0x3F	on	on	on	on	on	on
	Dec. 0 1 2 3 62	0 0x00 1 0x01 2 0x02 3 0x03 62 0x3E	Dec. Hex (2°) 0 0x00 off 1 0x01 on 2 0x02 off 3 0x03 on 62 0x3E off	Dec. Hex (2°) (2') 0 0x00 off off 1 0x01 on off 2 0x02 off on 3 0x03 on on 62 0x3E off on	Dec Hex (2°) (2') (2²) (2²) 0 0x00 off off off 1 0x01 on off off 2 0x02 off on off 3 0x03 on on off 62 0x3E off on on	Dec. Hex (2°) (2¹) (2²) (2²) 0 0x00 off off off off 1 0x01 on off off off 2 0x02 off on off off 3 0x03 on on off off 62 0x3E off on on on	Dec. Hex (2°) (2¹) (2²) (2²) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°) (2°)



I/O Format:



repetition = 8 msec.

Identifier:

_	Messa	Message Priority Future Use					J1939 Reference Proprietary B									Da	ta Fie	eld Ty	pe*			Not	Used		N	lode 1	D**		
Example –	1	0	0	0	0	1	1	1	1	1	1	1	1	0	1	0	1	0	0	1	1	0	0	1	1	1	1	1	1
Identifier Bit No. –	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Hex Value –			()			F	=			ı	=			5	5			3	3			3	3			ı	=	

^{*}Sensor field data can be factory set to customer specific value.

Data Field:

 $\mathbf{B_0}$ = LSB current measurement count byte

B₁ = MSB current measurement count byte

 $\mathbf{B_2}$ = not used

 $\mathbf{B_3} = \text{not used}$

B ₄ = error flag B ₅ = error flag	Velocit	ty Data	Error	Flags	Not	Used	Curr Measur Cor		
B ₆ = LSB velocity data byte B ₇ = MSB velocity data byte	B ₇	В ₆	B ₅	B ₄	В ₃	B ₂	B ₁	B ₀	



Current Measurement Count

The Current Measurement Count (CMC) is the output data that indicates the present position of the measuring cable. The CMC is a 12-bit value that occupies bytes $\mathbf{B_0}$ and $\mathbf{B_1}$ of the data field. $\mathbf{B_0}$ is the LSB (least significant byte) and $\mathbf{B_1}$ is the MSB (most significant byte).

The CMC starts at 0x008 with the measuring cable fully retracted and continues upward to the end of the stroke range stopping at 0xFE5. This holds true for all ranges.

Converting CMC to Linear Measurement

To convert the current measurment count to inches or millimeters, simply divide the count by 4061 (total counts over the range) and then multiply that value by the full stroke range:

$$\left(\frac{\text{current measurement}}{\text{count}}\right) \times \text{full stroke} \\ \text{range}$$

Sample Conversion:

If the full stroke range is **80 inches** and the current position is **0x4FF** (1279 Decimal) then,

$$\left(\frac{1279}{4061}\right)$$
 X 80.00 inches = 25.2 inches



Error Flags



RED and GREEN Indicator LEDS (controller board)


0x00 (GREEN - ON, RED - OFF) indicates the sensor is operating within normal calibrated limits.

0x33, 0x55, 0xAA, 0xCC (RED or GREEN - FLASHING) indicates sensor is at or beyond it's calibrated measurment range. Should any of these conditions occur within calibrated range, return unit to factory for evaluation or service.



Velocity

Data in bytes ${\bf B_7}$ - ${\bf B_6}$ is the change in the CMC (current measurement count) over a 100 msec time period. This data can then be used to calculate velocity in a post processing operation.



Velocity Calculation

$$\left(\frac{\text{count change - 2047}}{\text{.1 sec. time period}}\right) X \left(\frac{\text{full stroke range}}{4061}\right)$$

Sample Calculations

Cable Extension (positive direction):

 $B_7..B_6 = 0x8D3$ (2259Dec), full stroke = 80 in.

$$\left(\frac{2259 - 2047}{.1 \text{ sec}}\right) X \left(\frac{80 \text{ in.}}{4061}\right) = 41.76 \text{ in./ sec.}$$


Cable Retraction (negative direction):

 $B_7..B_6 = 0x7D0$ (2000Dec), full stroke = 80 in.


$$\left(\frac{2000 - 2047}{.1 \text{ sec}}\right) \chi \left(\frac{80 \text{ in.}}{4061}\right) = -9.26 \text{ in./ sec.}$$

^{**}Customer defined, set via Dips 1-6. Bit values shown for example only, see Address Setting below.

80-inch SGJ-80-4 w/ Mounting Bracket:



120-inch SGJ-120-4 w/ Mounting Bracket:



celesco

tel: 800.423.5483 • +1.818.701.2750 • fax: +1.818.701.2799


Mounting Options:

Changing Measuring Cable Exit and Electrical Connector Direction:


For the ultimate in flexibility, the measuring cable exit direction and the direction of the electrical connector can be rotated around in 90° increments to accommodate just about any installation requirement.

To change measuring cable exit direction, simply remove the 4 mounting bracket screws, rotate the bracket to desired position and replace the screws.


To change the direction of the electrical connector, remove the 4 sensor cover screws and carefully remove the sensor cover just far enough to separate the cover from the main body. Be careful of the three small gage wires that attach the internal controller board to the potentiometer.



Mounting Option Mounting Dimensions (SGJ-80-4):



Mounting Option Mounting Option Dimensions (SGJ-120-4):



version: 1.0 last updated: January 23, 2013

