

TESTING INSTRUMENTS FOR
A MEASURABLE DIFFERENCE...

IDM
instruments

EXTENSIOMETER FOR FABRIC

MODEL: IDM-E0004-M1



INTRODUCTION

The methods of tests in this standard are applicable to woven, and to warp-knitted fabrics. They are particularly applicable to stretch fabrics such as are obtained by the use of elastomeric fibres or bulked yarns, or by a process such as slack mercerization. A specimen of standard dimensions is stretched by applying a specified load. The extension is observed, and the tension removed. The length of the unstretched specimen is observed after recovery.

APPLICATIONS

- Woven Fabric
- Knitted Fabric

FEATURES

- Includes 2 X Cutting templates
- Adjustable clamps

STANDARDS

- BS 4952

OPTIONAL ITEMS

- Spare Weights

DIMENSIONS

Instrument:

- H: 100 mm
- W: 125 mm
- D: 435 mm
- Weight: 15 kg

WARRANTY AND CALIBRATION SERVICES

- **1 year Warranty**
- Our **Preventive Maintenance and Calibration (PM&C) program** has been designed to make the maintenance and calibration of your valuable testing equipment more cost effective by preventing breakdowns and downtime by regular calibration, service and replacement of defective parts. Talk to us about this today.